EXCAVATOR DRUM MULCHER



The Blue Diamond® Extreme Duty **Excavator Drum Mulcher** is one of the fastest ways to tear down a forest. Turn trees to wood chips in minutes using our durable drum mulcher built with high strength steel.

No job is too big or small with cutting widths up to 50 inches. All our drum rotors have fixed teeth set in helical position with "p-cut" depth limiters. Choose the reversible carbide teeth option for maximum tooth lifespan when working in rocky areas! And with

centralized grease points and hydraulic quick couplers, you can trust that routine maintenance is straightforward and easy.

The Extreme Duty model comes with a double row of chains to keep material flowing and shield the operator from thrown debris. centralized grease points and hydraulic guick couplers, you can trust that routine maintenance is straightforward and easy.

APPLICATIONS INCLUDE:

High Strength Steel



Wear Resistant Steel Skids

KEY FEATURES

- ◆ Available in 40" & 50" cutting widths
- ◆ Variable displacement 50-85CC piston motor
- ◆ Required pressure 4,000-5,500 PSI
- Synchronous drive system
- ◆ Chain curtain minimizes discharge
- Input counterblade that is adjustable & bolted for easy replacement
- Brush rake options available
- ◆ Requires case drain, hoses & couplers





Hydraulic adjustable door





Labeled hose & grease ports



Agricultural Property Upkeep

Stump Removal

Forestry Applications

Bite limiters

PART NO.	190555	190565	190551
MODEL	40" EXTREME DUTY EXCAVATOR DRUM MULCHER	50" EXTREME DUTY EXCAVATOR DRUM MULCHER	SEVERE & EXTREME DUTY BRUSH RAKE OPTION
MOTOR SIZE	50-85 CC	50-85 CC	_
HOST MACHINE	FITS 24K-37K MACHINES	FITS 24K-37K MACHINES	_
MIN-MAX FLOW	32-45 GPM	32-45 GPM	_
WEIGHT*	1,700 LBS	1,850 LBS	625 LBS

*Weight is without mount. Excayator Drum Mulchers do not come with hoses or couplers. Host machine requires case drain and may require additional hydraulic valve for aux flow. All these items are dealer responsible for time and materials. Manufacturer suggested time (MST) is 1-hour shop required to tune the mulcher to the host machine, and this time excludes all other dealer installed service items. Ask your sales rep. for detailed installation instructions.